



How To Reset The Gap Of Your SplitFire Spark Plugs Cómo fijar la luz en las bujías SplitFire

1 All spark plugs — old or new — must have their gaps adjusted before being installed. Use a round wire feeler-gauge of the thickness specified by your service manual. Pull the gauge through the gap between the two electrodes. If the gap is correct, the gauge will pass through it smoothly with only a slight amount of friction detectable.




2 If the gap is incorrect, fit the notched bending bar of a spark plug tool over the side electrode and gently bend the metal to narrow or widen the gap. Use the feeler-gauge to check the gap. Do not be discouraged if it takes you several tries to set the gap correctly; few professionals get it precisely right on their first — or their second — effort.




3 To adjust the side electrode, gently twist the center “V” configuration over electrode to return it to the proper positioning as shown.


Be sure to follow these steps with each plug in your set.



1 Todas las bujías tanto nuevas como viejas deben tener la luz ajustada antes de la instalación. Use un calibre de espesores redondeado del espesor especificado por el manual de servicio. Pase el calibre por el espacio entre los dos electrodos. Si la luz es correcta, el calibre pasará por la misma sin problemas, sólo con una ligera fricción detectable.



2 Si la luz es incorrecta, ajuste la barra de flexión dentada de una herramienta para bujías sobre el lateral de los electrodos y con cuidado flexione el metal a fin de reducir o aumentar la luz. Use el calibre de espesor para verificar la luz. No se desaliente si necesita de varios intentos para fijar la luz de manera correcta; pocos profesionales lo hacen con precisión en el primer o segundo intento.



3 Para ajustar el electrodo lateral, gire ligeramente el electrodo a tierra sobre el electrodo central para regresarlo a la posición correcta, tal como se ilustra.

Asegúrese de seguir estos pasos con cada bujía que fije.



Vehicle Manufacturers' Warranties Garantías del fabricante del vehículo

SplitFire® Spark Plugs are produced to meet **all** OEM specifications. If you are told by your dealer or mechanic that you must use original equipment only and that the use of a replacement spark plug like SplitFire® voids a vehicle's warranty, **ask to get that in writing!** This type of “tie-in” sales tactic is generally illegal under federal law (the Magnuson-Moss Warranty Act). Unless your dealer or mechanic offers to provide the part for free or unless he tells you in writing that your vehicle will not work properly without it, insist on quality SplitFire® products.

Las bujías SplitFire® se fabrican a fin de cumplir con todas las especificaciones de los fabricantes. Si el fabricante o mecánico le indica que de usar sólo equipos originales y que el uso de bujías de reemplazo, tales como SplitFire® anula la garantía del vehículo, ¡solicítelo por escrito! Este tipo de táctica de venta “promocional” es generalmente ilegal en virtud a las leyes federales (Ley de garantías Magnuson-Moss). Salvo que el fabricante o mecánico ofrezca brindar la parte sin cargo o salvo que le indique por escrito que el vehículo no funcionará apropiadamente sin la misma, insista en obtener productos de calidad SplitFire®.